



Bona R848

PERFORMANCE FOR MODERN NEEDS

Rapid initial bonding strength



Hard-elastic 1C silane adhesive with great rib stability.

Bona R848's properties make it particularly suitable for the installation of parquet with low movement, such as engineered and mosaic parquet. It reduces tension in the sub-floor and hardens by reacting with moisture. The use of a primer is generally not necessary.

- High initial bonding strength
- Good adhesion to most substrates
- Designed for engineered flooring
- Water and solvent free



Bona R848

PERFORMANCE FOR MODERN NEEDS

Rapid initial bonding strength

TECHNICAL DATA

Product type / base:	Silane-modified prepolymer
Colour:	Beige
DIN EN ISO 17178:	Hard-Elastic
Giscode:	RS10
Open time:	approx. 30 mins*
Curing time:	Light foot traffic after approx. 12 hrs.* Full cure 24–48 hrs.* Application of surface treatments should only proceed after full cure. *at 20 °C and 55 % RH.
Cleaning agents:	Bona Cleaning Wipes, acetone, ethanol. Hardened adhesive can only be removed mechanically
Shelf life:	Bucket: 12 months / Tubular bag: 24 months from date of production in unopened original bucket/tubular bag.
Storage/Transport:	The temperature must not fall below +5 °C or exceed +25 °C during storage and transport. Store in a cool, dry, well-ventilated place. Protect from frost.
Disposal:	Waste and emptied containers should be handled in accordance with local regulations.
Pack size:	15 kg bucket & 1 kg, 4.5 kg, 6 kg and 9 kg tubular bags
Certificates/approvals:	EMICODE: EC 1PLUS French VOC: A+ DIBt: Z-155.10-128

Additional detailed information is noted in the appropriate Safety Data Sheet.



Bona R848

PERFORMANCE FOR MODERN NEEDS

Rapid initial bonding strength

SUBFLOOR PREPARATION

The subfloor must be even, dry, clean, free from cracks, residues and contamination, and be physically sound. The subfloor must comply with local regulations with regard to flatness and surface strength and should be slightly textured to achieve optimum adhesion.

Separating layers, weak surface layers, laitance and contaminants must be mechanically removed.

The moisture content of the subfloor must be measured in accordance with local standards.

All surfaces must be thoroughly vacuum cleaned prior to adhesive application.

A primer is not normally required. However, to improve adhesion or to strengthen a weak top layer of the subfloor, an appropriate Bona primer should be used. Refer to the relevant product Technical Data Sheet.

Where residual construction moisture needs to be suppressed, a moisture barrier primer such as Bona R540 or Bona R590 may be used (refer to the relevant product TDS

for instructions). Alternatively, Bona R848 may be used to suppress residual construction moisture without the need for an additional moisture barrier primer, provided it is applied correctly (see details in “Application Instructions” below). If in doubt, contact Bona Technical Support.

This product is described as a “moisture barrier” in line with common industry terminology. It functions by reducing and slowing water vapour transmission and is not designed to fully block vapour movement. It cannot be considered equivalent to a dedicated structural damp proof membrane.

Bona R848 is suitable for adhering approved wood flooring for use in conjunction with underfloor heating. Such subfloors must be slowly and gradually dried and warmed in accordance with the heating-up protocol. During installation and for 3 days after, the screed temperature must not exceed 25 °C. Always follow the flooring manufacturer’s instructions.

SUITABLE SUBSTRATES

- Cementitious screed (CT) according to EN 13813
- Floors levelled with levelling compounds (at least 2 mm thick, resistant against plasticiser migration)
- Calcium sulfate screed (CA) according to EN 13813
- New chipboards (P4-P7) or OSB 2 – OSB 4 boards, tightly screwed.
- Other dry and sound subfloors, such as gypsum fibre boards.
- Mastic asphalt screed (AS) according to EN 13813 - contact Bona technical support for application details.
- Can also be used on deep-cleaned metal surfaces - contact Bona technical support for application details.
- Bona underlays like Bona U310, U340 & U350.
- Concrete



Bona R848

PERFORMANCE FOR MODERN NEEDS

Rapid initial bonding strength

APPLICATION INSTRUCTIONS

Flooring must be correctly acclimatised so that it is stable with the installation environment. Depending on the species and type of flooring this can typically vary between 3 and 14 days, always follow the flooring manufacturer's guidance. A stable indoor environment must be maintained in the long term to reduce the risk of expansion and contraction and associated issues.

Before using the adhesive, the indoor air temperature should be a minimum of 18 °C, floor temperature: min. 15 °C, max. 20 °C (including with underfloor heating); max. 70 % RH. The adhesive must be acclimatised to room temperature. After opening the bucket, remove the protective foil and any hardened adhesive at the edges. The adhesive should be applied evenly using a notched trowel appropriate to the flooring being laid (see guidance in the next section).

The parquet should be laid into the adhesive and pressed down firmly during the open time of approx. 30 minutes. If the adhesive on the subfloor develops a skin, remove it and apply new adhesive. If any adhesive is forced through the joints onto the face of the boards, remove it carefully as it may affect the adhesion of any subsequent oil or lacquer finish. Any adhesive on prefinished surfaces should be removed with Bona Cleaning Wipes.

Bona R848 can be used for directly bonding dimensionally stable parquet types on cementitious substrates (excluding cement-based levelling compounds or gypsum based materials/screeds) with residual construction moisture content exceeding the normally accepted level, without the need for an additional moisture barrier primer, **provided the**

concrete/screed surface is free of all visible dampness.

It cannot prevent other issues originating from the top, sides or ends of flooring (water leaks, puddles, hydrostatic head, etc.) nor does it eliminate other moisture or installation-related issues such as improper acclimation of flooring, the effects of jobsite temperature and humidity or the lack of a functioning structural damp proof membrane within the subfloor build-up. In addition to being visibly dry, the subfloor must meet the usual requirements for parquet installation; in particular, it must be sufficiently cured (≥ 28 days), clean, sound, level and properly prepared. For heated floor constructions, the multi-stage heating protocol must have been implemented. To ensure secure and robust bonding, the adhesive must be applied with a Bona Trowel Plus (application rate between 2000 and 2200 g/m², depending on the roughness of the subfloor), and the parquet must be laid into the adhesive within the open time. When applying the adhesive, ensure complete wetting of both the subfloor and the parquet. Skirting boards must be moisture-resistant or ventilated. After installation, the parquet must not be covered with vapour-tight or highly vapour-retardant materials until the subfloor is completely dry. This includes, in particular, vapour-tight films, e.g., made of PE (painter's plastic sheeting), certain mats & carpets (with dense, rubber-like backing), or TetraPak® films. You must provide the following trades and the end user with appropriate instructions.

Bona R848 cures by reacting with moisture. To prevent premature curing from moisture vapour in the air, promptly replace the foil on the surface of the adhesive and the lid on the container during use.



Bona R848

PERFORMANCE FOR MODERN NEEDS

Rapid initial bonding strength

CONSUMPTION

8–10 mm Mosaic parquet

Bona Trowel 850F or 850G

(TKB B3/B6, ISO 6076 12T/11T)

Usage: approximately 850 g/m²

2 layered prefinished parquet

Bona Trowel 1000F or 1000G

(TKB B8/B10, ISO 6076 14T/16T)

Usage: approximately 1000 g/m²

3 layered prefinished parquet

Bona Trowel 1250F or Bona 1250G

(TKB B11/13, ISO 6076 16T/20T)

Usage: approximately 1250 g/m²

Use as a moisture barrier

Bona Trowel Plus

Usage: 2000–2200 g/m² (depending on surface roughness)

(F = fine, G = coarse)

Use a fine trowel for small pieces of wood and/or smooth subfloors, and a coarse trowel for large pieces of wood and/or rougher surfaces.

If using the Bona OptiSpread system, please refer to the respective machine manual for application guidelines.

The information in this document and all other advice and recommendations that we provide to help and assist the applicator are based on previous experience and extensive testing but makes no claim to be complete. Because of the wide range of possible uses and conditions of application of our products, we do not relieve users from the need to carry out their own trials or to seek technical advice from Bona before use. Bona can only guarantee its products and not the construction as a whole. Observe recommendations from flooring manufacturer and the provisions of relevant standards.